


| Item# | Part Code     | Description               |
|-------|---------------|---------------------------|
| 1     | BH8PR10000-01 | MAIN PUMP SET 10T         |
| 2     | BH8PR10000-02 | RUBBER SADDLE             |
| 3.1   | BH8PR4000-03  | OPEN CLAMP                |
| 3.2   | BH8PR10000-03 | EXTENSION TUBE 145 mm     |
| 4     | BH8PR10000-04 | EXTENSION TUBE 245 mm     |
| 5     | BH8PR10000-05 | EXTENSION TUBE 345 mm     |
| 6     | BH8PR10000-06 | EXTENSION TUBE 595 mm     |
| 7     | BH8PR10000-07 | SQUARE SADDLE             |
| 8     | BH8PR10000-08 | OFFSET SADDLE WITH THREAD |
| 9     | BH8PR10000-09 | OFFSET SADDLE             |
| 10    | BH8PR10000-10 | SHARP SADDLE              |
| 11    | BH8PR10000-11 | CONNECTION PART           |
| 12    | BH8PR10000-12 | WORK PISTON SET 10T       |
| 13    | BH8PR10000-13 | OIL HOSE                  |
| 14    | BH8PR10000-14 | ROUND SADDLE              |
| 15    | BH8PR10000-15 | CROSS SADDLE              |
| 16    | BH8PR10000-16 | PLASTIC CASE              |
| 19    | BH8PR4000RC   | RAM CONNECTOR             |
| 20    | BH8PR4000-20  | HOSE CONNECTOR            |



BH8PR10000

Revision: 01



16



*SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe.*