

■小麦粉（一般的な薄力粉）

N	モード		
	ケアフル	ノーマル	クイック
1	100.4	100.3	106.0
2	100.5	100.6	104.3
3	100.3	101.1	103.0
4	100.4	100.2	100.9
5	100.2	100.7	105.0
6	100.5	101.4	104.0
7	100.4	100.7	104.5
8	100.3	101.0	104.2
9	100.5	100.5	106.5
10	100.6	100.7	104.8
11	100.4	/	/
12	100.1		
13	100.5		
14	100.3		
15	100.8		
16	100.8		
17	100.5		
18	100.6		
19	100.1		
20	100.5		
平均値	100.4	100.7	104.3
中央値	100.5	100.7	104.4
標準偏差	0.19	0.35	1.48
CV値	0.18%	0.34%	1.42%
MIN値	100.1	100.2	100.9
MAX値	100.8	101.4	106.5
平均時間（s）	32.2	27.1	15.3

■小麦粉（サラサラタイプ_薄力粉）

N	モード		
	ケアフル	ノーマル	クイック
1	100.9	100.3	109.6
2	101.1	100.6	109.6
3	101.1	100.7	110.2
4	100.9	100.8	110.5
5	100.8	101.4	108.7
6	100.6	100.9	108.3
7	100.7	100.7	109.4
8	100.6	101.4	110.1
9	100.6	100.9	112.1
10	101.0	100.5	111.5
11	100.8	/	/
12	100.2		
13	101.1		
14	100.4		
15	100.9		
16	101.1		
17	100.2		
18	101.1		
19	100.7		
20	100.5		
平均値	100.8	100.8	110.0
中央値	100.8	100.8	109.9
標準偏差	0.28	0.34	1.11
CV値	0.28%	0.33%	1.00%
MIN値	100.2	100.3	108.3
MAX値	101.1	101.4	112.1
平均時間（s）	15.8	11.9	8.7