

Test Report	
Customer	tantore Co.,Ltd.
Name of information	22 Mukaigo, Mukoukusama Town, Toyohashi Aichi 441-8142,Japan tantore Co., Ltd.
Name of sample	Clear Electromagnetic Shield Mesh
Manufacturer	tantore Co.,Ltd.
Issue date	2021/7/2

Main measurement instruments used in this test	
Name	Measurement range
Spectrum Analyzer	Frequency: 3Hz~42.98GHz; Level: +30dBm~-130dBm;
Signal generator	Frequency: 250kHz~40GHz; Power(-135~15)dBm
Test information	
Ambient temperature : 22°C	Humidity : 55%RH
Way for receipt : sent by customer	Status of sample : Normal
Received date : 2021/07/01	Date for test : 2021/07/02
The data are valid only for the sample	

Test sample

width: 108-109cm	weight: 60g-70g/m2	thickness: 0.08mm-0.09mm
Resistance: <1ohm	Shielding efficiency: 50-70db	

1.Results of shielding effectiveness test

Clause	Frequency(MHz)	SE(dB)
4	30	69.7
	100	7.4
	300	74.8
	915	76.4
	1500	78.9
	2450	86.1
	3000	82.3
	5000	80.7
	8000	81.3
	10000	82.9
	12000	80
	14000	80.7
	16000	80.6
	18000	79.4
	20000	76.7
	22000	77.4
	24000	75.8
	26000	76
	28000	74.1
	30000	74.5
32000	73.7	
34000	77	
36000	75.9	
38000	74	
40000	71.1	