

ASTM法シールド性能試験結果

測定日 : 2023年 6月 7日

気温 24℃ / 湿度 60% / 気圧 996hPa

Version 1.00

#

周波数 [MHz]	シールド効果[dB]	
	EMSシートNH	EMSシートWH
1000	120.05	52.23
1100	120.15	50.54
1200	122.35	51.37
1300	121.86	49.81
1400	122.03	48.65
1500	123.78	49.82
1600	123.03	48.97
1700	124.36	49.81
1800	121.93	47.85
1900	121.27	46.88
2000	122.83	49.05
2100	119.46	48.23
2200	119.55	49.06
2300	120.51	48.10
2400	120.86	47.67
2500	121.22	47.83
2600	121.47	47.49
2700	122.45	47.77
2800	120.36	45.79
2900	120.68	45.15
3000	122.57	47.56
3100	122.56	46.13
3200	119.05	45.08
3300	123.89	47.53
3400	119.43	48.89
3500	118.34	46.20

周波数 [MHz]	シールド効果[dB]	
	EMSシートNH	EMSシートWH
3600	120.68	47.68
3700	118.38	47.04
3800	114.83	45.46
3900	118.22	46.14
4000	113.13	44.52
4100	114.78	46.21
4200	114.50	45.73
4300	111.40	44.67
4400	114.21	47.89
4500	115.02	46.34
4600	107.83	43.98
4700	113.78	46.76
4800	111.13	45.77
4900	107.49	43.93
5000	108.55	45.67
5100	110.39	46.59
5200	107.30	46.89
5300	114.59	48.86
5400	112.33	50.35
5500	114.01	49.58
5600	129.52	47.74
5700	120.56	49.30
5800	107.33	48.48
5900	97.11	45.86
6000	99.24	45.55

ASTM法シールド性能試験結果

